VAP©RTEK Restorator DUO® Instructions For Use

LED INDICATOR
SOLID GREEN = Ready to use.

Fig. 1 Turn on switch at top of unit. If LED indicates low battery, attach AC adapter & charge for 3-6 hours. ON

0 Fig. 3

BLINKING GREEN = Charging. Insert open end of cartridge into back of machine, seating ¿rmly against internal gasket. BLINKING RED = Recharging required NO LIGHT = Recharging required.

Fig. 2 Turn off machine. Lift off cartridge lid & discard clear ; Im liner. Cartridge life is rated at 270 hours.

Fig. 4

This unit delivers odor-neutralizing dry vapor for permanent odor control. It does not produce ozone, hydroxyl, or any added moisture. This product is safe to use in occupied spaces. For use instructions, safety guidelines, and cartridge best practices, please visit us online.

Retain lid for storage setain ind for storage by placing against back of cartridge. Install spring-loaded latch bar into grooves, against cartridge lid, & twist to lock into place.

For maximum performance, replace cartridge after 270 hours of use.

120 Volts 60 Hertz 11 Watts

for use & operation manual visit WWW.VAPORTEK.COM